

# **Indoor Femto Lite Gateway**

## **WLRRTES – 106V2**

### **User Manual**

## Revision History

Revision	Date	Description	Author
.Draft	Nov. 08, 2023	<ul style="list-style-type: none"><li>• New naming</li></ul>	Vincent
.001	Jan. 17, 2024	<ul style="list-style-type: none"><li>• Add Dual-WAN</li></ul>	Bill Lu
.002	May. 14, 2024	<ul style="list-style-type: none"><li>• Login page</li><li>• Reset Button function</li></ul>	Sui Fan-Jiang



## Copyright

© 2021 BROWAN COMMUNICATIONS INC.

This document is copyrighted with all rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means without the written permission of BROWAN COMMUNICATIONS INC.

## Notice

BROWAN COMMUNICATIONS INC. reserves the right to change specifications without prior notice.

While the information in this manual has been compiled with great care, it may not be deemed an assurance of product characteristics. BROWAN COMMUNICATIONS INC. shall be liable only to the degree specified in terms of sale and delivery.

The reproduction and distribution of the documentation and software supplied with this product and the use of its contents are subject to written authorization from BROWAN COMMUNICATIONS INC.

## Trademarks

The product described in this document is a licensed product of BROWAN COMMUNICATIONS INC.

# Contents

---

<b>REVISION HISTORY .....</b>	<b>1</b>
<b>COPYRIGHT .....</b>	<b>2</b>
<b>NOTICE.....</b>	<b>2</b>
<b>TRADEMARKS.....</b>	<b>2</b>
<b>CONTENTS.....</b>	<b>3</b>
<b>CHAPTER 1 – INTRODUCTION .....</b>	<b>4</b>
Purpose and Scope.....	4
Product Design.....	4
Definitions, Acronyms, and Abbreviations.....	5
Reference.....	5
<b>CHAPTER 2 – HARDWARE DETAILS .....</b>	<b>6</b>
.....	6
LED Indicators.....	6
I/O Ports .....	7
Back Label.....	8
Package Label.....	8
Package Content .....	8
<b>CHAPTER 3 – USER MANUAL .....</b>	<b>10</b>
3.1 Connect Indoor Femto Lite Gateway .....	10
3.2 Indoor Femto Lite Gateway Setting.....	10
STEP 1: Firmware Upgrade.....	12
STEP 2: SET LORA.....	13
STEP 3 : SET WAN .....	19

## Chapter 1 – Introduction

---

### Purpose and Scope

The purpose of this document is to describe the main functions, supported features, and system architecture of the WLRRTES-106V2 Indoor Femto Lite Gateway based on the latest LoRaWAN<sup>®</sup> specification.

### Product Design

The purpose of this document is to describe the main functions, supported features, and system architecture of the WLRRTES-106V2 Indoor Femto Lite Gateway based on the latest LoRaWAN<sup>®</sup> specification.






## Definitions, Acronyms, and Abbreviations

Item	Description
LPWAN	Low-Power Wide-Area Network
LoRaWAN®	LoRaWAN® is a Low Power Wide Area Network (LPWAN) specification intended for wireless battery-operated Things in a regional, national, or global network.
ABP	Activation by Personalization
OTAA	Over-The-Air Activation
TBD	To Be Defined

## Reference

Document	Author
LoRaWAN® Specification v1.0.3	LoRa Alliance®
RP002-1.0.1 LoRaWAN® Regional Parameters	LoRa Alliance®

## Chapter 2 – Hardware Details



### LED Indicators


- LED sequence: Power(System), WAN, Wi-Fi, LoRa®
- Solid LED is for static status, blanking means the system is upgrading or active devices linked to the corresponding port.

	Solid On	Blinking	Off
Power System (Blue)	Power ON	Booting / Config Mode	Power Off
WAN (Blue)	Ethernet Plugged and got IP Address	Connecting	Unplug
Wi-Fi (Blue)	WiFi Station Mode and got IP Address	Connecting	Wi-Fi Disabled
LoRa® (Blue)	LoRa® is working	Connecting	LoRa does not work

Table 1 LED Behaviors

## I/O Ports

Port	Count	Description
RJ45	1	WAN port of the device
Reset	1	Reset to default (5 seconds to reset settings to factory default)
Micro USB	1	Power input via USB adaptor(5VDC/2A)




*Figure 1 – IO Ports*



## Back Label

The marking information is located at the bottom of the apparatus.



## Back label




Figure 2 – Back Label

## Package Label

N o.	Item	Description
1	Product BOX	Brown Box
2	Labeling	Model/ MAC/ Serial Number/ Type Approval

## Package Content

N o.	Description	Quantity
1	The product	1



2	Power adapter (100-240VAC 50/60Hz to 5VDC/2A)	1
3	Ethernet Cable 1 meter (UTP)	1


## Chapter 3 – User Manual

---

### 3.1 Connect Indoor Femto Lite Gateway

You can connect to the gateway via Wi-Fi or Ethernet interface. The WIFI AP SSID and password (for both WIFI and GUI) are printed on the back label by default.

Figure 3 – Back Label



The rule of gateway WIFI AP SSID is **MerryIoT\_Hub-XXXX**, where the last digits are the last 4 digits of the MAC address

The WIFI interface of your PC will fetch the IP address of range 192.168.4.x except 192.168.4.1 assigned by the AP.

The Ethernet status of the device in Default or Config mode is static IP: 192.168.55.20/24. The PC could also access the GUI of this device by setting its IP to: 192.168.55.X/24.

### 3.2 Indoor Femto Lite Gateway Setting

Open the web browser(ex: Chrome) after connecting to the gateway via WIFI AP IP address "192.168.4.1" or Ethernet IP address "192.168.55.20".

For security purposes, the user also has to input the **Password** on the back label as the GUI password to get into the settings pages.



esp32-wifi-manager

Not secure 192.168.4.1

Web Service: Connected.

## Authentication Required

Password:

Please refer to the back label.

Login

Figure 4 – WEB UI-1

Web Service: Connected.

## MerryIoT Hub Setting

STEP 1. SET OTA MODE

Configure OTA Mode

STEP 2. SET LORA

Configure LoRa Setting

STEP 3. SET WAN

☒ Ethernet  
☐ Wi-Fi  
☐ Dual WAN

Connection Check Address 1:

localhost

Connection Check Address 2 (Optional):

ex: 8.8.8.8

Figure 5 – WEB UI-1

ETHERNET STATUS

Protocol: Static IP  
IP Address: 192.168.55.20  
Subnet Mask: 255.255.255.0  
Default Gateway: 192.168.55.1  
DNS 1: 8.8.8.8  
DNS 2: -

Figure 6 – WEB UI-2

ETHERNET SETTING	
(Please connect ethernet cable before setting.)	
<input checked="" type="radio"/> Static IP	
<input type="radio"/> DHCP	
IP Address:	<input type="text" value="192.168.55.20"/>
Subnet Mask:	<input type="text" value="255.255.255.0"/>
Default Gateway:	<input type="text" value="192.168.55.1"/>
DNS 1:	<input type="text" value="8.8.8.8"/>
DNS 2 (Optional):	<input type="text"/>
<input type="button" value="Apply"/>	

Figure 7 – WEB UI-3

Now you can configure the gateway through the WEB GUI.

## STEP 1: Firmware Upgrade

The gateway supports firmware upgrades through the OTA method.

### STEP 1. SET OTA MODE

#### Configure OTA Mode

Figure 8 – Configure OTA Mode

Click the “Configure OTA Mode”.

CURRENT FIRMWARE VERSION	
v1.0.14	
OTA SERVER DAILY CHECK	
<input checked="" type="radio"/> Disable	
<input type="radio"/> Enable	
<input type="button" value="Cancel"/>	<input type="button" value="Save"/>

Figure 9 – Configure OTA Mode

**CURRENT FIRMWARE VERSION** – display the current firmware version.

**OTA SERVER DAILY CHECK** – Enable or Disable the firmware upgrade through OTA mode. The gateway will check the OTA server every 24 hours interval. It will upgrade automatically if there is the latest firmware on the OTA server.



The OTA server has to be configured by the Python tool. Please contact BROWAN for any support.

Click the “Enable” and “Save” buttons to enable the OTA or “Disable” functions.

#### OTA SERVER DAILY CHECK

- ☐ Disable  
☒ Enable

Cancel

Save

Figure 10 – Enable OTA

## STEP 2: SET LORA

Click “Configure LoRa Setting” to configure the LoRa function/parameters.

#### STEP 2. SET LORA

Configure LoRa Setting

Figure 11 – Configure LoRa Setting

There are two modes for the LoRa configuration.[Basic Station and Packet Forwarder]

#### MODE

- ☒ LoRa Basics™ Station  
☐ LoRa Packet Forwarder

Figure 12 – LoRa Mode

## STEP 2.1 Basic Station mode

Select the “LoRa Basics Station” mode. The CUPS server and LNS server have to be configured when the gateway is in the Basic Station mode.



**MODE**

☒ LoRa Basics™ Station  
☐ LoRa Packet Forwarder

**LORA BASICS™ STATION**

Gateway EUI: 80029CFFFE2B29E1  
☒ Enable CUPS

**CUPS**

Type: ☒ Boot ☐ Regular  
CUPS URI:

☒ Install CUPS Trust [installed]  
 No file chosen

☒ Install CUPS CRT [installed]  
 No file chosen

☒ Install CUPS Key [installed]  
 No file chosen

Figure 13 –Basic Station mode

**Enable CUPS** – The CUPS server is a configuration and update server. Enable or Disable the CUPS server according to the network architecture.

Enable the CUPS server if it is necessary for the network.

**Type** – The certificate type of the CUPS.[Boot/Regular]



The gateway will search “Regular” type of certificate for the priority if you select the “Boot” type. It will search “Boot” type of certificate if the gateway can not find the “Regular” type of certificate.

**CUPS URI** – The CUPS server address. Enable and install the CUPS trust/CRT/Key if the CUPS server needs a certificate.

Type: ☒ Boot ☐ Regular  
CUPS URI:

☒ Install CUPS Trust [installed]  
 No file chosen

☒ Install CUPS CRT [installed]  
 No file chosen

☒ Install CUPS Key [installed]  
 No file chosen

Figure 14 – Install CUPS certificates

**LNS Server** – The LNS server is the LoRaWAN® Network Server. LNS establishes a data connection between a LoRa Basics™ Station and a LoRaWAN® network server.

## LNS

LNS URI:

wss://A7DOL17DOWWULL.gateway.lorawan.us-east-1.amazon

☒ Install LNS Trust [non-install]

Choose File

☒ Install LNS CRT [non-install]

Choose File

☒ Install LNS Key [non-install]

Choose File

Figure 15 – LNS server/certificates

**LNS URI** – The LNS server address. Enable and install the LNS server trust/CRT/Key if the certificate is necessary for the LNS server.

## STEP 2.2 LoRa Packet Forwarder mode

Select the “LoRa Packet Forwarder” mode.

### MODE

☐ LoRa Basics™ Station

☒ LoRa Packet Forwarder

Figure 16 – LoRa Packet Forwarder mode

Configure the **Gateway Info/Radio setting/Channel Assignment** for the packet forwarder mode.





## LORA PACKET FORWARDER

### Gateway Info

Gateway ID: 000080029C2B29E1

Server Address:

localhost

Server Uplink Port (1~65535):

1700

Server Downlink Port (1~65535):

1700

Keep Alive Interval (seconds):

10

Statistics Display Interval (seconds):

30

Push Timeout (milliseconds):

100

Figure 17 – Gateway settings

**Radio Settings** – configure the central frequency in Hz.

#### Radio 0 Settings

Central Frequency (Hz):

904300000

#### Radio 1 Settings

Central Frequency (Hz):

905000000

Figure 18 – Radio settings

**Channel Assignment** – configure the center frequency offset of each channel.



## Channel Assignment

☒ Enable Channel 0

Radio Interface: ☒ radio 0 ☐ radio 1

Center Frequency Offset (Hz):

-400000

☒ Enable Channel 1

Radio Interface: ☒ radio 0 ☐ radio 1

Center Frequency Offset (Hz):

-200000

☒ Enable Channel 2

Radio Interface: ☒ radio 0 ☐ radio 1

Center Frequency Offset (Hz):

0

☒ Enable Channel 3

Radio Interface: ☒ radio 0 ☐ radio 1

Center Frequency Offset (Hz):

200000

Figure 19 – Channel Assignment-1



# BROWAN

☒ Enable Channel 4

Radio Interface: ☐ radio 0 ☒ radio 1

Center Frequency Offset (Hz):

-300000

☒ Enable Channel 5

Radio Interface: ☐ radio 0 ☒ radio 1

Center Frequency Offset (Hz):

-100000

☒ Enable Channel 6

Radio Interface: ☐ radio 0 ☒ radio 1

Center Frequency Offset (Hz):

100000

☒ Enable Channel 7

Radio Interface: ☐ radio 0 ☒ radio 1

Center Frequency Offset (Hz):

300000

☒ Enable Lora Standard Channel

Radio Interface: ☒ radio 0 ☐ radio 1

Center Frequency Offset (Hz):

300000

Channel Bandwidth (Hz):

☐ 250K ☒ 500K

Channel Spread Factor:

☐ SF7 ☒ SF8 ☐ SF9 ☐ SF10

Figure 20 – Channel Assignment-2

## STEP 3 : SET WAN

The gateway supports either “Ethernet” or “Wi-Fi” or “Dual WAN” connection as the internet backhaul.

### STEP 3. SET WAN

- ☒ Ethernet
- ☐ Wi-Fi
- ☐ Dual WAN

Figure 21 – WAN connection

### STEP 3.1 Connection Check Address Setting

Schedule the WAN monitor to periodically check if this address can be pinged, in order to confirm the connectivity. If connecting to the local network, you can fill in "**localhost**". For an external connection, you can use "**8.8.8.8**" or another IP address.

Connection Check Address 1:

localhost

Connection Check Address 2 (Optional):

ex: 8.8.8.8

Figure 22 – Connection Check Address

### STEP 3.2 Ethernet Setting

Configure the IP address of WAN.[Static IP/DHCP client]



### STEP 3. SET WAN

- ☒ Ethernet
- ☐ Wi-Fi
- ☐ Dual WAN

Connection Check Address 1:

localhost

Connection Check Address 2 (Optional):

ex: 8.8.8.8

### ETHERNET STATUS

Protocol: Static IP  
IP Address: 192.168.55.20  
Subnet Mask: 255.255.255.0  
Default Gateway: 192.168.55.1  
DNS 1: 8.8.8.8  
DNS 2: -

### ETHERNET SETTING

(Please connect ethernet cable before setting.)

- ☒ Static IP
- ☐ DHCP

IP Address:

192.168.11.10

Subnet Mask:

255.255.255.0

Default Gateway:

192.168.11.1

DNS 1:

8.8.8.8

DNS 2 (Optional):

8.8.4.4

Figure 23 – Static IP connection

**ETHERNET STATUS** – The information of IP address/Subnet Mask/Gateway/DNS.

**ETHERNET SETTING** - Configure the IP address of WAN.[Static IP/DHCP client]

**Static IP** – Setup the IP address/Subnet Mask/Default Gateway/DNS of the static IP.



Contact the network administrator for the static IP address information.

**DHCP** – The IP address/Subnet Mask/Default Gateway/DNS will be assigned by the DHCP server.

After selecting "Static IP" or "DHCP", click "Apply" to connect network.

**ETHERNET SETTING**

(Please connect ethernet cable before setting.)

☐ Static IP


☒ DHCP

Apply

Figure 24 – DHCP client connection

## STEP 3.3 Wi-Fi

Select "Wi-Fi" to be the internet backhaul connection.



The gateway WiFi interface is the Access Point by default which SSID is "MerryloTHub-XXXX" printed on the back label. The administrator can only access the WEB UI through the Access Point mode to configure the gateway. The gateway will be the WiFi client and will not be able to access the WEB UI after enabling the WiFi interface as the internet backhaul connection.

**STEP 3. SET WAN**

☐ Ethernet

☒ Wi-Fi

☐ Dual WAN

Connection Check Address 1:

localhost

Connection Check Address 2 (Optional):

ex: 8.8.8.8

**WI-FI MANUAL CONNECT**

ADD (HIDDEN) SSID

**OR CHOOSE A WI-FI...**

AP-010070

!@#%&\*\_+[]{}<?>.,/;[]=-

crux2

Figure 25 – Wi-Fi connection

**MANUAL CONNECT** – Specify the remote AP SSID and enter the password if necessary.

Click "Join" to accept or "Cancel" to abort.

**MANUAL CONNECTION**

LoRa gateway

.....|

Cancel

Join

Figure 26 – Wi-Fi manual connection



The gateway will scan the nearby access point automatically. Just click the SSID for the WiFi connection.

OR CHOOSE A NETWORK...















garyhome	 
SSAK3	 
ALHN-8B78	 
HITRON-C150	 
Eric	 
dlink-E4DC	 
YT-VLC-2G	 

Figure 27 – Wi-Fi manual connection

Enter a WiFi password if it is necessary for the connection.

PASSWORD FOR ALHN-8B78

Password

Cancel

Join

Figure 28 – Wi-Fi password

Click “Join” to accept or “Cancel” to abort.

## STEP 3.4 Dual WAN

DUAL WAN CONFIGURATION consists of three steps in total. The first step will display the network setting priority, please select “**Ethernet First**” or “**Wi-Fi First**”. After selecting, click “**Next**”.

**STEP 3. SET WAN**

☐ Ethernet  
☐ Wi-Fi  
☒ Dual WAN

Connection Check Address 1:

Connection Check Address 2 (Optional):

**DUAL WAN CONFIGURATION (1/3)**

**DUAL WAN SETTINGS**

Network Priority:  
☒ Ethernet First  
☐ Wi-Fi First

Next

Figure 29 – Dual WAN Settings

In the second step, please select whether to use “**Static IP**” or “**DHCP**”. After selecting, click “**Next**”.

**DUAL WAN CONFIGURATION (2/3)**

**ETHERNET STATUS**

Protocol: Static IP  
IP Address: 192.168.55.20  
Subnet Mask: 255.255.255.0  
Default Gateway: 192.168.55.1  
DNS 1: 8.8.8.8  
DNS 2: -

**ETHERNET SETTING**

(Please connect ethernet cable before setting.)  
☐ Static IP  
☒ DHCP

Next

Figure 30 – Dual WAN Settings

In the third step, please select the Wi-Fi SSID you want.



**DUAL WAN CONFIGURATION (3/3)****WI-FI MANUAL CONNECT**

ADD (HIDDEN) SSID

**OR CHOOSE A WI-FI...**

AP-010070



!@#\$\$%^&amp;\*\_{:}?&gt;&lt;.,/;[=-



crux2

*Figure 31 – Dual WAN Settings*

Enter your Wi-Fi password and click **“Join”** to connect network or **“Cancel”** to abort.

Web Service: Connected.

**Enter Password****PASSWORD FOR PRISMOFFICE-SW**

••••••••

Cancel

Join

*Figure 32 – Dual WAN Settings*

The final screen that the GUI will display.

Web Service: Disconnected.

**Please wait...****CONNECTING TO AP-010070**

WiFi starts connecting...  
AP mode will be disabled after connection successful.  
Please check status from LED.

OK

*Figure 33 – Final screen*


To get into the **Config mode** (not restore), you could press and hold the Reset button longer than 2 sec and shorter than 10 sec (with LED indicator **slow** blink), and release it. You could connect to the device's WIFI AP and configure LoRa/Network/OTA again in this mode.

If you want to reset and enter the initial GUI screen, you can press the Reset button for 10 seconds (with LED indicator **fast** blink) or command “**restore\_default**” and then “**restart**”, so that the AP MODE can be displayed again to enter the GUI.



Figure 34 – Wi-Fi broadcast AP MODE

After clicking AP MODE to connect, you can fill in “**192.168.4.1**” on the web page and enter the initial GUI screen.



## Authentication Required

Password:

Please refer to the back label.

Login

Figure 35 – Login Page



Web Service: Connected.

MerryIoT Hub Setting

STEP 1. SET OTA MODE

Configure OTA Mode

STEP 2. SET LORA

Configure LoRa Setting

STEP 3. SET WAN

☒ Ethernet  
☐ Wi-Fi  
☐ Dual WAN

Connection Check Address 1:

localhost

Connection Check Address 2 (Optional):

ex: 8.8.8.8

Figure 36 – The Setting screen

## Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### IMPORTANT NOTE:

#### Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Country Code selection feature to be disabled for products marketed to the US/CANADA

Operation of this device is restricted to indoor use only

**Industry Canada statement:**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference
- (2) This device must accept any interference, including interference that may cause undesired operation of the device

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**Radiation Exposure Statement:**

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

**Déclaration d'exposition aux radiations:**  
Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé. Cet équipement doit être installé et utilisé à distance minimum de 20cm entre le radiateur et votre corps.